



## AOC - Oil Cooler Parts

Item	Part No.	Description
	<b>10248</b>	Complete Oil Cooler Assembly - AOC (Direct or Remote Mount)
2	<b>1916</b>	Heat Exchanger and Motor Assembly
3	<b>1463</b>	Motor for Heat Exchanger (Motor Only)
4	<b>1890</b>	Motor & Pump Combination with Coupling
5	<b>13412</b>	Oil Pump (Pump Only)
6	<b>13411</b>	Oil Pump Motor (Motor Only)
7	<b>15527</b>	Oil Pump & Motor Coupling (Between Motor & Pump)
8	<b>13410</b>	Air Filter for Front of Heat Exchanger
9	<b>19475</b>	Thermostat for Oil Cooler
10	<b>19119</b>	Filter Head with Sight Gauge 10 Micron Filter
11	<b>1953</b>	Oil Filter Replacement (10 Micron Filter - Standard)
12	<b>17465</b>	Oil Filter Replacement (3 Micron Filter - Optional)
13	<b>19340</b>	Suction Hose 1" x 8'-0" Long (U416 1" I.D. SEA 100R4)

Item	Part No.	Description - Options
	<b>21755</b>	Remote Weather Protection Housing
	<b>19919</b>	Cold Weather Kit
	<b>21895</b>	Oil Cooler Pump Seal

## BOL - Oil Cooler Parts

Item	Part No.	Description
	<b>20856</b>	Complete Oil Cooler Assembly - BOL
2	<b>20916</b>	Heat Exchanger and Motor Assembly
3	<b>20917</b>	Motor for Heat Exchanger (Motor Only)
4	<b>1890</b>	Motor & Pump Combination with Coupling
5	<b>13412</b>	Oil Pump (Pump Only)
6	<b>13411</b>	Oil Pump Motor (Motor Only)
7	<b>15527</b>	Oil Pump & Motor Coupling (Between Motor & Pump)
8	<b>19475</b>	Thermostat for Oil Cooler
9	<b>19119</b>	Filter Head with Sight Gauge 10 Micron Filter
10	<b>1953</b>	Oil Filter Replacement (10 Micron Filter - Standard)
11	<b>17465</b>	Oil Filter Replacement (3 Micron Filter - Optional)
12	<b>12793</b>	Hose 3/4" I.D. x 50' Long Hydraulic Low Pressure
13	<b>19340</b>	Suction Hose 1" I.D. x 8'-0" Long (U416 1" ID SEA 100R4)
14	<b>20982</b>	Duct Screwing Flange

Item	Part No.	Description - Options
	<b>21755</b>	Remote Weather Protection Housing
	<b>19919</b>	Cold Weather Kit